LG IP 8800 series

User Guide



Phones overview





IP 8815



IP 8820



IP 8830



IP 8840




Common components






Basic keys





Navigation controls

- IP 8820 / IP 8830 / IP 8840 only
- Used to
 - navigate in menus on the screen
 - Access Call log and Phone Book when phone is idle





Basic telephony features



How to place a call ?

- Type the number and pickup the handset (or the other way around)
 - To remove last digit, press the \leftarrow softkey
 - To cancel, press the **EndCall** softkey
- You can also type the speed number (0-99) associated with a contact in your phone book
- Press the **Call** softkey to confirm or wait 2s
- To place a call in speaker mode, just don't pickup the handset
- To redial your last number, press the **Redial** softkey



How to answer / refuse a call ?

- Pickup the handset
- To answer using the speaker:
 - Press the **Answer** softkey
 - Or, press the **Speaker** button
- To refuse a call, press the **Refuse** softkey



How to end a call ?

- Press the **EndCall** softkey
- Or, Replace the handset
- Or press the **Speaker** button when in speaker mode



Hold / Mute

- How to mute a call?
 - Press the Mute button.
 - The microphone is muted and you continue to hear your contact
- How to set a call on hold?
 - Press the Hold button or Hold softkey
 - Music is played to the caller



Transfer

- Press the **Transfer** softkey
- Type the number to transfer to
- Press **Call** or wait 2s
 - Speak to third party and press **Transfer** again to confirm the Transfer
 - Or press EndCall, then Resume to retrieve the caller
 - You can also press Transfer before 3rd party answers (kind of blind Transfer)



Transfer (2)

- You can also do a « Blind transfer »
 - Third party will see that the call comes from initial caller
 - Press the **BlindXfr** softkey
 - You'll need to navigate in the softkey's using the right arrow (or **Next** softkey on IP 8815)
 - Type the number
 - Press the Call softkey or wait 2s
 - The phone is now free



Advanced telephony features



Conference

- Press the **Conferen** softkey
- Type the 3rd party number
- Press **Call** or wait 2s
 - Speak to third party and press **Join** to start the conference
 - Or press EndCall, then Resume to cancel
 - You can also press **Join** before 3rd party answers
- Conference ends when the guy who organized the conference hangs up.



Multiple calls

- How to answer a call while you are on the line?
 - Phone show « Call Waiting » « 2/2 » and you hear a bip
 - Press Answer softkey within 2 seconds to take the call
 - After 2s press the Down arrow to switch to the second call
 - Previous call is put on Hold.
- How to switch between active calls? (except IP 8815)
 - Press up or down arrow
 - You have the current remote party on the line
 - Screen is updated with the remote party name and number
 - Previous call is put on Hold
- How to return to previous call when current call is finished?
 - Press the **Resume** softkey to unhold



Voicemail & Call history



How to listen to your voicemail?

- When you have a new voicemail
 - Phone will play a bip and display « New message arrived »
 - Message LED will blink
- Access your voicemail using the Voicemail button (or Hold button on IP 8815)
- Screen will show how many New and Old messages you have
- Press the **Dial** softkey to call your voice mailbox





IP 8815



How to consult the Call history ?

- Press the Up key (except IP 8815)
- Or, Press the Dir. List softkey then navigate to Call log
- Choose 1. Missed Calls, 2. Received Calls or 3. Placed Calls and press OK
- Navigate in your call history
- Use **Dial** softkey to call back
- Use Right button to show other options : Delete, Edit, Save, Del. All (IP 8815 : Next→ softkey)
- **Del. All** will delete all call history entries of that category



Phone preferences



Settings

- IP 8815: Press the Settings/Transfer button when the phone is idle Press the same button to exit
- IP 8820 / IP 8830 / IP 8840: Press the Settings button left to the navigation controls Press the same button to exit







Change the screen contrast

- Access the Settings
- Navigate to 3. Phone Settings
- Press OK
- Navigate to **1. LCD Contrast**
- Adapt the contrast using **Down** and **Up** softkeys
- Changes are applied immediately
- Exit the menu using Left button (IP 8815 : Hold button)





Change the ringtone

- Access the Settings
- Navigate to 3. Phone Settings
- Press OK
- Navigate to 2. Ring Settings
- Press OK
- Press OK again to enter 1. Default Ring Type
- Navigate in the ringtones and press **Play** to listen to the current ringtone
- Press OK to confirm your choice
- Exit the menu using **Left** button (IP 8815 : **Hold** button)

Ring Setting >1.Default Ring	Туре		
↑ Previous	Next	ОК	
Default Ring Set *Type1	tting		
↑ Play	Next	ок	



Change the language

- Access the Settings
- Navigate to 3. Phone Settings
- Press OK
- Navigate to 11. Language
- Choose your language
- Press OK
- The phone's display language is now updated
- Exit the menu using **Left** button (IP 8815 : **Hold** button)

4					08:30
	nguage nglish				
₽	Previous	Ne	xt	OK	(



Contacts management



Add a Contact

- Press the **Dir.List** softkey or **Down** button (except IP 8815)
- Navigate to 1. Phonebook and press OK
- Navigate to the Add softkey using Right button (IP 8815 : use Next→) and press Add
- Type the name. You can press Mode to enter digits or capital letters, ← to remove last character. Confirm by OK
- Type the number and confirm by **OK**
- Choose a ring type and confirm by **OK**
- Choose a Speed number (erase existing using **Clear**). You'll be able to call your contact using that short number.
- Press OK

부		08	: 30
Phone Book (>(01)Tom,123	-		
↑ Previous	Next	Dial	l →

¥*		08:	30
Phone Book	(Page 1)		
>(01)Tom,123	34		
🚹 Edit	Add	Delete	₽

ᅷ			08:30
Phone Book 9876	: Number	c	123
Δ ←	Mode	OK	→



Save a contact from Call history

- Press the **Up** key (except IP 8815)
- Or, Press the **Dir. List** softkey then navigate to **Call log**
- Choose 1. Missed Calls, 2. Received Calls or 3. Placed Calls and press OK
- Navigate in your Call history
- Use **Dial** softkey to call back
- Use Right button (IP 8815 : Next→ softkey) to show Save and press Save
- Follow the screens like if you would Add a contact

Edit a Contact

- Press the Dir.List softkey or Down button (except 8815)
- Navigate to 1. Phonebook and press OK
- Navigate to the contact you want to edit using Up and Down buttons (except IP 8815) or Previous and Next softkeys
- Navigate to softkey Edit using Right button (IP 8815 : Next→ softkey)
- Press Edit
- Make the changes you want and press OK on each screen
- Phone displays « Saved »

Phone Book (P >(01)Tom,1234	age 1)		
↑ Previous	Next	Dial	→

	one Book 1)Tom,12	(Page 1) 34		
τ	Edit	Add	Delete	→



Delete a Contact

- Press the **Dir.List** softkey or **Down** button (except 8815)
- Navigate to 1. Phonebook and press OK
- Navigate to the contact you want to delete using Up and Down buttons (except IP 8815) or Previous and Next softkeys
- Navigate to softkey **Delete** using **Right** button (IP 8815 : Next→ softkey)
- Press Delete
- Phone displays « Data will be lost. Are you sure ? »
- Confirm by **Yes**

4		08:30
Phone Book	(Page 1)	
>(15) Tommy	,9844	
↑ Edit	Add	Delete 🗲

Data will be lost. Are you sure?	꾸	Jan 23	08:30	
			•	
Yes No	Yes		No	



Find a Contact

- Press the **Dir.List** softkey or **Down** button (except 8815)
- Navigate to 1. Phonebook and press OK
- Navigate to softkey Find using Right button (IP 8815 : Next→ softkey) and press Find
- Phone displays « Search for : »
- Type your search query and press **OK**



Corporate Directory

- Press the Dir.List softkey or Down button (except 8815)
- Navigate to 2. Remote Phonebook and press OK
- You can search based on the name
- Enter your search query and press **OK**
- Press the Left button (IP8815 : Hold) to make a new query
- Enter a result using **OK**
- You can see the Extension, Mobile and Home number associated with the contact. Choose the entry you want to call and press **Dial**



Various



How to reboot the phone ?

- Press the **Settings** button
- Navigate to **9. Reboot** using **Next** softkey or **Down** arrow
- Press **OK**
- Phone will display « System will be rebooted. Are you sure? »
- Confirm by **Yes**



How to reset the phone ?

- Press the **Settings** button
- Navigate to 6. Set to Default using Next softkey or Down arrow
- Press OK
- Phone will display « Will be set to default. Are you sure? »
- Confirm by **Yes**
- Phone will display « Set to default now. Wait a moment »
- When you leave the Settings menu, the phone will display « You need to reboot. Reboot now? »
- Press **Yes** to reboot

